GLOBO

FAN

0431S/0431SA



DC5V ⎓ 2A 10W

GLOBO Handels GmbH
Gewerbestrasse 3
A-9184 Sankt Peter
Austria
www.globo-lighting.com
office@globo-lighting.com

CE III







1	Tilting Fan Head	5	USB Charging Cable
2	Fan Blade	6	Lamp
3	Swing (Oscillating) Pivot	7	Control Panel
4	Charging Port on Rear	8	Indicator Lights



Vertical Angle
0 - 90°



A	Indicator Lights
B	Lamp On / Off Button
C	Power On / Off Button
D	Fan Speed Button
E	Swing Button (on or off)

Speeds



Low-1450 rpm/min
Mid-1650 rpm/min
High-2000 rpm/min

Oscillation



LED lamp

1x0.3W LED 5V 6500K incl.







incl.1x0.8m
Type-C cable









1x3.7V 2500mAh Li-ion battery incl.

AKKU DATA

LI-Ion 18650 RECHARGEABLE

*Manufacturer:ZHUHAI GREAT POWER ENERGY CO., LTD.
Adress:(BUILDING A,WORKSHOP) NO.2 XINQING FIFTH ROAD,
JING'AN TOWN, DOUMEN DISTRICT, ZHUHAI CITY, GUANGDONG PROVINCE,P.R.China
Model: GP-18650-1S1P 18650 Li-ion 2500mAh 3,7V

SAFETY INSTRUCTIONS



Anleitung zum Akkuwechsel / Battery replacement instruction

Step 1

1.First, turn the product over,
then peel off the four anti-slip foot
pads on the bottom.



Step 2

2.Remove the four screws on
the bottom with a Phillips screwdriver.



Step 3

3.Simply disconnect the battery terminal from the connector on the PCBA, then you can replace the battery



Step 4

4.install the bottom cover, tighten the screws, then re-attach the anti-slip foot pads that were peeled off earlier.

