

GLOBO
FAN

0440S/0440H



220-240V~50/60Hz 50W

GLOBO Handels GmbH
Gewerbestrasse 3
A-9184 Sankt Peter
Austria
www.globo-lighting.com
office@globo-lighting.com



1 Screw KA3*8
2 Front grill
3 Blade nut
4 Blade
5 Screw TM5*8
6 Back grill
7 M5 hand knob
8 Screw TM8*45
9 Body
10 Swing control
11 Switch knob
12 Screw TM4*8
13 M8 nut knob
14 Electric wire
15 M6 hand knob
16 Pipe
17 Iron base
18 Heavy
19 Plat meson
20 M10 seven knob



Figure 1




Figure 2




Figure 3

Figure 1: assemble the column pipe, chassis and counterweight block together with M8 hand screw and 8mm flat medium.

Figure 2: assemble the fuselage and column tube with M8 nuts and screws TM8*45.

Figure 3: fix the rear net on the fuselage with four TM5 * 8 screws.




Figure 4




Figure 5





Figure 6


Figure 4: fix the fan blade on the shaft core with plastic nuts.

Figure 5: fix the front net on the fuselage with 8 KA3 * 8.


Figure 6: figure 6 shows the assembled wall fan.























Low-1000 rpm/min
Mid-1100 rpm/min
High-1200 rpm/min

